



PRODUCT SPECIFICATIONS REPORT

FOR GASOLINE ENGINES ONLY

Zep Throttle Plate Cleaner removes deposits on your cars throttle plate. If your car stalls while it's idle or driving, use our Throttle Plate Cleaner to improve its air and fluid flow. Zep Throttle Cleaner will definitely have your car running smooth and efficient again.

THROTTLE PLATE CLEANER

PROD. #1047445

Vehicle Maintenance – Carb & Choke Cleaners



FEATURES BENEFITS

Catalytic converter & Oxygen sensor safe
For gasoline engines only
Removes varnish, resin & gum deposits
Improves idle quality & efficiency

DIRECTIONS

1. Turn engine off and remove air induction hose from the throttle body.
2. Place shop towel under throttle body to soak up dissolved deposits and spent cleaner.
3. Open throttle to the wide open position.
4. Liberally spray both sides of the throttle place, vacuum and idle control ports and surrounding air intake area.
5. Wipe out accessible area with a shop towel.
6. Re-install air induction hose.
7. Start the engine - run at 1500 RPM for one minute.

COMPANION PRODUCTS

Carb Cleaner

SPECIFICATIONS

Physical Form	Aerosol
Color	Clear
Odor	Solvent-like
Flammability	Extremely Flammable
Shelf Life	5 years
D.O.T. Shipping Label	ORM-D

PACKAGING

12-12 oz. case/net weight

Zep Sales & Service
www.zep.com
1-877 I BUY ZEP