



PRODUCT SPECIFICATIONS REPORT

Use Zep Mass Air Flow Sensor Cleaner every time your air filter is replaced to increase your car's gas mileage and horse power while reducing emissions. Your Mass Air Flow Sensor keeps your air/fuel ratio balanced at 14.7:1. If your check engine light is on, it can be a sign that your Mass Air Flow Sensor is dirty. Use our Mass Air Flow Sensor Cleaner to prevent unnecessary repairs and costs.

MASS AIR FLOW SENSOR CLEANER

PROD. #1047448

Vehicle Maintenance – Electronics Cleaner



FEATURES BENEFITS

Maintains proper air/fuel ratio
Restores lost performance
Fast drying

DIRECTIONS

1. Turn the engine off and locate the MAF sensor, generally a small device located in the fresh air tube just behind the air filter.
2. Disconnect the connector.
3. Remove the retaining screws and pull the sensor from the air duct.
4. Use a shop towel to absorb any excess fluid.
5. Spray the sensor for about 5-7 seconds to clean it. Do not use any brushes or tools to clean the sensor.
6. Let the sensor dry briefly.
7. Reinstall it and start the engine.

RECOMMENDATION: Clean the MAF sensor each time the air filter is replaced.

SPECIFICATIONS

Physical Form	Aerosol
Color	Clear
Odor	Aliphatic, solvent-like
Flammability	Extremely Flammable
Shelf Life	5 years
D.O.T. Shipping Label	ORM-D

PACKAGING

12-11 oz. case/net weight

Zep Sales & Service
www.zep.com
1-877 I BUY ZEP